## THE LOCOMOTIVE IN SERVICE



LONDON:
THE LOCOMOTIVE PUBLISHING CO., LTD.
3 AMEN CORNER. E.C.4.

## CONTENTS.

						PAGE
	LOCOMOTIVE DRIVING					I
	FIRING AND CARE OF BOILERS					5
\	PROTECTING BOILER PLATES					22
	BAD STEAMING ENGINES					24
	Fire-grates					27
	Brick Arches in Fireboxes					31
	VALUE OF FUEL					35
	Superheating					37
	EXPANSION OF STEAM AND W	ORK IN	THE C	YLINDE	ERS	54
	TESTING VALVES AND PISTONS	in Ste	AM			57
	ENGINE FAILURES AND REMEI	DIES				67
	REPAIR ORGANIZATION					100
	Connecting Rod Big Ends					108
	REFITTING BIG END BRASSES	and Ax	LE Box	BRASS	SES	IIO
	Hot Axle Boxes					III
	RE-METALLING AND FITTING E				ERS	114
	REGRINDING STEAM COCKS					115
	METHOD OF RECORDING AXLE	Box F	LAY			116
	THE LIFTING SHED					119
	HYDRAULIC WHEELDROPS FOR	RUNN	ING SH	IEDS		120
	LEVER FOR PULLING SPRINGS	INTO P	OSITION	V		123
	Lubrication					124
	STEAM BRAKES					134
	Brake Rigging					141
	Sanding		• • •			150
	WEIGHT DISTRIBUTION					152
	SHED MANAGEMENT					157
	Breakdown Tools and Tack	KLE			'	168
	THREE CYLINDER COMPOUND	Locom	OTIVES			178
	BRITISH STANDARD HEADLIGH	T INDI	CATION	S		185
	SPEED TABLE					187